

WGA-01

WGA-01 is used in the following instruments:

- Weld Wide Ar-Gone
- Sumner Ar-Gone

Parts Required:

- R-33S1
- 2 x OEM Label
- 1 x Sensor label
- 1 x Barcode label
- Sensors Bag

Conversion Procedures:

- 1) Change the polarity of the R-33S1 sensor at the Molex connector.
- 2) Provide Derek with the barcodes of the R-33S1 sensors. Inform Derek or Cathy of the Model (WGA-01) and the company name to be on the sensor (Weld Wide or Sumner). Derek can then convert the sensor on Intrastats and print 2 labels for each sensor using the Citizen Printer.
- 3) Remove original Teledyne label and replace with new OEM label.
- 4) Add the second label to the sensor bag, add the sensor and heat seal, Add final barcode label.

