May 14, 1998

Mr. Chris Fontana Medical Cables Inc. 1340 Logan Ave. Costa Mesa Ca. 92626

Dear Chris:

Listed below is the final test process that each of the Pulse Oximeter probes are subject to prior to shipping them to you;

100% functional test is performed by a trained operator, placing the probe on the finger attached to the appropriate pulse oximeter box. Each probe must show an active pulse and > 93% oxygen saturation.

The probes are then cleaned with alcohol and inspected for visual defects.

A functional test audit is performed next by a trained Quality Assurance Inspector, using the same test method listed above. The test is performed at AQL 1.5 level II. This equals 13 PCs from each 50-piece lot. Pass on zero failures, fail lot on 1 failure.

A trained Quality Assurance inspector performs a final visual inspection.

The probes are then serialized and placed in a bag with the appropriate lot traceability information written on the inspection label.

Regards