

VANDAGRAPH

COMPANY OPERATING PROCEDURE

Mixcheck Battery holder construction VM3/COP/40.70

Date: 22-05-09

Revision Date: 30-Sep-13

Issue: 1

Parts Required

CPC battery Holder BT03721 or Farnell 118310

Farnell Molex 3 way header 143-127

Farnell Crimp Pin x2 977 3789

793007 Battery lead

Method

1. Add crimps to Red & Black wires of the battery lead 793007
2. Insert crimps into 3 way header observe correct polarity

