



Work Instructions & Test Methods

Refer to customers drawing

Select material ,either 5mm Perspex clear cast or 10 mm Acrylic

Mark position of bends and slots

Cut out slots

Using heater and jig bend along drawn line

Smooth all edges with fine emery paper and flame polish

Clean and polish

QA

Check finished product against customers drawing

Check all edges for smoothness

Check that no imperfections are present

Wrap in protective wrapping