

Work Instructions & Test Methods.

- 1) Use appropriate drawing and mark out position of bends, and where appropriate, all relative holes and accompanying slots
- 2) Using heater and jigs bend Perspex along drawn line.
- 3) Where appropriate, cut out slots / holes to marked out lines
- 4) Smooth down all edges with fine emery cloth and flame polish.
- 5) Smooth all edges.
- 6) Check that no imperfections are present
- 7) Check the finished item against the customer requirements
- 8) Clean, polish and wrap.