



Work Instructions & Test Methods

Headboxes

Refer to customers/master drawing

Select material , 10mm Perspex clear cast

Mark position of bends and slots

Using heater and jig bend along drawn line

Smooth all edges with fine emery paper and flame polish

Clean and polish

QA

Check finished product against customers/master drawing

Check all edges for smoothness

Check that no imperfections are present

Wrap in protective wrapping