



Supplement to Infant Radiator Instruction Manual (mobile stand).

Important notes for the assembly and use of the Infant Radiator mobile stand.

1. During assembly of the Infant Radiator mobile stand the bolts at the base of the lower upright connecting this part to the base unit should not be torque loaded over 17.6Nm.
2. The damper should be inserted into the upper section of the upright and retained by the locking pin in the lower 8mm holes. The extension bar should be screwed to the damper and the assembly inserted into the lower section of upright. Slightly compress the damper such that the two sections of upright can be locked together by screwing the hex drive bolt into the slot in the upper section of upright.