

Vandagraph			
DINKIT			
22/05/00	VM/COP/40.3	Issue 1	ver 1
		Page1	of 1

Din Kit comprises :-

1. A-268 Tee Adaptor (Blue 22mm M + 22mmF + 15mmF)
2. DM22M10 Male adapter (clear) 22mmM to 10 mm tubing adapter)
3. B-50057 Divertor
4. BS111 Viton O Ring (Oxygen compatible)
5. DIN 22F High Pressure Restrictor
6. VP12 Tubing 30 cm long

All items above assembled

Place in Clear bag with a leaflet Folder so that the Specification is visible and the DINKIT lies on top of the description.

Add the label

“DIN22F/KIT inc. 1 each

A-268 Tee Piece

B-50057 Flow Thru adapter

DM22M10 Male 22mm/10mm

VP12 30cm Tubing

DIN22F Pressure Restrictor

BS111 Viton O Ring “

QA & assembly of Individual Items

DIN 22F High pressure restrictor

1. Add O ring BS111
2. Check thread fits cleanly into an A clamp (Yoke)
3. Check threads for sharp edges
4. Check hole is visible
5. Add transparent Label (Vandagraph DIN22F

Tee Piece

- a. Warm tubing and fit to DM22M10 male adaptor
- b. Fit DM22M10 to Tee Piece A-268
- c. Add Divertor B-500057 to middle leg of Tee