

<b>COMPANY OPERATING PROCEDURES</b>				
<b>Procedure AN300 QA</b>				
Created:	27/03/06	VM3/COP/38.08	Issue1	1
Revised:	13 August 2009	Last printed 5/22/2009 12:33:00 PM	Page 1 of 1	

AN300

Open the box carefully and take out yellow case take out the sensor, analyser, battery and cable.

Take the batteries out of their plastic and put then in the analyser,

connect the cable and cell.

Check the on/off switch works.

Press the button for a few seconds until the count down starts,when calibration has finished the analyser should read 79.1.

Put a viamed label on the cell and re-seal it,

pack all the items back in the box and put a label on the outside then place whole unit back into the cardboard box and re-seal.

Ensure there is a bar code on the outside.