

## **COMPANY OPERATING PROCEDURES** Procedure GB300

**QA** Created: 27/03/06 **VM3/COP/38.07** Issue 11 Revised: 13 November 2009 Last printed 5/22/2009 12:33:00 PM Page 1 of 1

GB300

Open the box carefully and take out yellow case take out the sensor, analyser, battery and cable.

Take the batteries out of their plastic and put them in the analyser,

connect the cable and cell.

Check the on/off switch works.

Press the button for a few seconds until the count down starts, when calibration has finished the analyser should read 20.9.

Put a Viamed label on the cell and re-seal it,

Add a 0120099 Flow Divertor to the box.

pack all the items back in the yellow box and put a label on the outside then place whole unit back into the cardboard box and re-seal.

Ensure there is a bar code on the outside.