

Production Procedure 7900021

Weld Wide, Ar-Gone Oxygen Analyzer assembly

Install the following into assembly 7900020:

1 x 0110370 Oxygen Sensor, WGA-01 Weld Wide

Ensure that the analyzer reads 25.00 % +/- 2% when potentiometer fully +ve (clockwise).