

Production Procedure 7900031
Sumner Manufacturing,
Ar-Gone Oxygen Analyzer assembly

Install the following into assembly 7900030:

1 x 0110380 Oxygen Sensor, WGA-01 Sumner Manufacturing

Ensure that the analyzer reads 25.00 % +/- 2% when potentiometer fully +ve (clockwise).