

Production Procedure 7910020

Weld Wide, Ar-Gone Oxygen Analyzer assembly

Install the following into assembly 7900021:

1 x 9950055 Battery Alkaline Manganese 9V.

Test: Switch analyzer on ensure display reads **00.00**