

Production Procedure 7900031 Sumner Manufacturing, Ar-Gone Gas Analyzer assembly

Install the following into assembly 7900030:

1 x 0110380 Oxygen Sensor,
WGA-01 Sumner Manufacturing



Ensure that the analyzer reads 25.00 % +/- 2% when potentiometer fully +ve (clockwise).

