

## Production Procedure 7910030 Sumner Manufacturing, Ar-Gone Oxygen Analyzer assembly

Install the following into assembly 7900031:

1 x 9950055 Battery Alkaline Manganese 9V.



Test: Switch on analyzer, rotate calibration control to fully clockwise +ve position.

Ensure display reads **25.00 +/- 2.00**

