

VM3COP37.90 0121201 Pole Clamp

Remove the Maxtec Label and the extra bubble wrap.

Clean/remove the residue glue.



Add Clear Viamed label (pn: xxxxxxxx).

Note the Angle on the Mounting bracket and the screw.



Remove label from bag , add the barcode.

