

VANDAGRAPH COMPANY OPERATING PROCEDURE Oxygen Sensors

D-13 Sensor C Squared



VM3COP40.42

Compatible to C-Squared P/N 470019

Date: 20-Jun-2006

Revision Date: 11-Jul-11

Issue: 1



Parts Required

Quantity	Description	Part No.	
1	R22D Sensor		
1	White Box & Lid		
1	White wire 5 cm		
1	Black wire 5 cm		
1	Packing Material		
1	Round "Vandagraph" Label		
2	Serial number Labels		
1	Serial number Label for Outer bag		
1	Polythene Bag (outer)		

Procedure

1. Remove the rear of the sensor case VM3COP40.09
2. Remove the Molex VM3COP40.14x
3. Unsolder the three pins carefully
4. Remove solder from the holes
5. Add the wire to the outside holes and solder
6. The sensor PCD is marked Black & Red
7. Red is +ve Black is -ve
8. NB Colour is not important but Polarity to connector is.
9. Wired incorrectly monitor will read – before reading
10. White (or Yellow) is +ve Black (or Orange) is -ve

