

ASSEMBLY - PROCEDURE.**521A-6003068 Damper Kit Fit.**

Date: 14-July-03.

Revision date: 11-Jul-11.

Issue: 1.

Parts list.		
Qty.	Description.	Part No.
1	Damper Kit (includes damper, extension bar, 8mm diameter retaining pin and tube end fitting).	521A-6003068

Fitting Instructions.

1. Disassemble the mobile stand removing the upper portion of upright (if retro-fitting the damper kit).
2. Pass the damper through the tube end fitting such that the damper can be locked into the upright by the retaining pin passed through the 8mm holes on opposing sides.
3. Reassemble the mobile stand (if retrofitting the damper kit).
4. Push the stand down to its lowest height and ensure when released, the stand is forced to full height in a controlled manner.

NB. If an exchange upper half section is available, disregard item (2) & item (3) and remove the original upper half section of stand and fit a pre-machined section.