

### COMPANY OPERATING PROCEDURES

#### S&W 10-pin Socket 0010708

VM3/COP/36.17







Date: 3-Jul-02

Revision date: 13-Apr-11

Issue: 3



Each kit should contain the following components:

S&W 10-pin Side		
Qty	Description	Part No.
1	S&W 10-pin socket	0010708
(1)	 Rubber housing	
(1)	 Collar	
(7)	- Sockets	
(1)	 Upper casing	
(1)	- Cable clamp	
(1)	 (purple) Socket housing	
(2)	- Screws	
(1)	 Lower casing	
(1)	 (purple) Collar	

Procedure:

- 1) Place all the above items into a small plastic bag (9950203).
- 2) Using Lotus Smart Suite – Approach STKLABELS4, print a label as shown below and attach it to the bag and place in the appropriate docket.

0010708  
S&W 10 pin socket plug  
connector kit.  
Purple Insert, grey cover,  
4mm cable entry.