

VM3COP37.64 Teledyne Automotive Oxygen Sensor Packaging Procedure

Parts list:

Part number:

0150012
 9992523

Description:

Oxygen sensor box
 Label - Automotive Oxygen Sensor Viamed

Sensor list:

Part number:

0110107
 0110117
 0110127
 0110121
 0110122
 0110132
 0110137
 0110142

Senor type:

R-17A-LV
 R-17A
 R-17AV
 R-21A
 R-22A
 R-22AV
 R-17AH
 R-22AH

- 1) Check the serial number, part number and date code of the sensor. A corresponding label will be affixed to the outer packaging.
- 2) Take the sealed sensor and place it under the retaining film of the sensor box.
- 3) Using the fold lines, close the within the box.



- 4) Affix the box label to the box. The label must be straight and not overhang the box edges.



- 5) Affix the corresponding serial number label the front the box.

