

VM3COP37.63 Teledyne Medical Oxygen Sensor Packaging Procedure

Parts list:

Part number:

0150012

9992515

Description:

Oxygen sensor box

Label - Medical Oxygen Sensor Viamed

Sensor list:

Part number:

0110051

0110057

0110017

0110022

0110024

0110026

0110081

Senor type:

T-1 (No flow diverter)

T-7

R-17MED

R-22MED

R-24MED

R-26MED

UFO 130-2 (No flow diverter)

- 1) Check the serial number, part number and date code of the sensor. A corresponding label will be affixed to the outer packaging.
- 2) Take the sealed sensor and place it under the retaining film of the sensor box. If the sensor has a flow diverter included, then place the flow diverter under the retaining film with the sensor.



- 3) Using the fold lines, close the within the box.



- 4) Affix the box label to the box. The label must be straight and not overhang the box edges.



- 5) Affix the corresponding serial number label the front the box.

