FLOCAP® Flow Indicator





▶ FLOCAP Flow Indicator

The FLOCAP is a single-use CO_2 & flow indication device designed for visualization of a patient's exhaled CO_2 and expiratory flow. The CO2 indication will assist the user in verifying proper ET tube placement. The flow indicator helps the caregiver identify end of exhalation which may help prevent breath stacking and its associated health issues during resuscitation.

Part Numbers







- **1. 15mm Inlet**Connects to Resuscitation Bag
- **2. 22mm Outlet**Connects to ET Tube/Ventilator
- **3.** CO₂ Indication Label

 Colored by CO₂ range from 0 to 5%
- **4. Flow Indicator** *Visual Indication of expiratory flow*

5. Multi-Colored CO₂ Indicator Color ranges based on CO2 level

Specifications

Flow Sensitivity:	1LPM
CO ₂ Detection:	
Use Duration:	
Storage Temperature:	
Use Temperature:	
Internal Volume:	
Leak Rate:	
Compliance:	0.44 ml/kPa
Device Weight:	
Pressure Drop:	\dots 0.7 cmH ₂ O @ 30 LPM, 2.7 cmH ₂ O @ 60 LPM, 5.7 cmH ₂ O @ 90 LPM
Connector Port (Patient End):	
Connector Port (Ventilator End):	
Patient Size:	>15 Kg (33 lbs)

