




FLOWMETER 0-15LPM 02

FLOWMETER SPARES

0-15 LPM Flowmeter

6501-01	Flowmeter Outer Tube	3.00
6501-02	Flowmeter Inner Tube - O2	2.50
6501-04	Flowmeter Knob Label	0.50
6461	Flowmeter Control Knob - White (O2)	1.95
6501-15	Flowmeter Control Knob Screw	0.25
6600	Flowmeter Tubing Nipple	0.95
6601	Flowmeter Nebuliser Adapter	1.50
6461-01	Flowmeter Control Knob - Black (Air)	1.95
6502-02	Flowmeter Inner Tube - Air	2.50
6501-18	Flowmeter Nut	0.60
6501-19	Flowmeter Inlet	0.90

Low Flow Flowmeter

6582-02	Low Flow Flowmeter Inlet *	4.50
6589-01	Tube & Ball Assembly - 0-250cc	95.00
6582-04	Tube & Ball Assembly - 0-500cc	75.00
6586-01	Tube & Ball Assembly - 0-2.5 LPM	42.00
6575-01	Tube & Ball Assembly - 0-5 LPM	42.00