

MAKROLON® 2405, 2407, and 2458

Product Information

Polycarbonate Resins

2405 General-Purpose, High-Productivity Grade 2407 General-Purpose, High-Productivity, UV-Stabilized Grade

2458 General-Purpose, High-Productivity, FDA-Quality Grade

Description

Makrolon 2405, 2407, and 2458 polycarbonate resirts are linear, low-viscosity, high-performance thermoplastics produced in pellet form for processing primarily by injection molding. A unique technology enables these polycarbonates to maintain mechanical properties similar to lower-melt-flow grades of standard polycarbonate, while offering improved flowability for increased design flexibility. Makrolon 2407 resin is UV-stabilized. All three resins contain an internal mold release additive. They are available in natural clear, clear tints, and transparent, translucent, and opaque colors, and with special visual effects.

By broadening the processing window, Makrolon 2405, 2407, and 2458 resins are designed to permit faster cycling and higher productivity. Based upon tests conducted at Bayer laboratories, a processing comparison of Makrolon 2405 polycarbonate resin with production runs of standard polycarbonate has demonstrated increases in production rates in excess of 15%. Actual test results may vary, depending on the application and processing conditions. In addition, the increased productivity reduces energy consumption on a unit part basis.

These benefits are the result of low melt viscosity and ease of part ejection. The low viscosity is of particular interest in applications where thin walls exist or the flow length-to-wall thickness is high. Ease of processing at lower temperatures translates to faster cycles, as parts may be produced at lower mold-set-point temperatures and ejected after shorter cooling times. Although applicable to existing tools, new tool design can take advantage of the low melt viscosity of these grades. Thinner runners and distribution systems can be employed to minimize regrind and reduce cycle time. Wall sections in the part can be reduced to conserve materials and contribute faster cycling.

Although small parts offer some of the more attractive benefits of increased productivity, these grades are also candidates for applications involving large injection molded parts. In both large and small part molding, the same processing allowances exist. Lower melt temperatures and easy release permit demolding with less time necessary for stabilizing the part.

Makrolon 2458 resin complies with FDA food-contact regulations 21 CFR 177.1580 (Polycarbonate Resins) and may be used in contact with all food types. Most colors may be used for all thermal food-contact applications. However, some colors are limited by Conditions of Use B, 21 CFR 175.300 and 176.170 and may not be used when the food is sterilized in the food-contact article under autoclaving conditions. Please contact your Bayer Corporation representative with complete details when food contact is involved.

Makrolon 2458 resin, in natural 000000 and clear tints 550042 and 550115, is also listed under NSF standard 51 for use in food equipment. Please consult your Bayer Corporation representative for more information about food equipment applications.

Applications

Makrolon 2405, 2407, and 2458 resins are utilized over a wide range of applications in a variety of market areas. Typical applications include automotive light pipes, clear windows for business machines and instruments, and numerous consumer applications where multicavity tooling is used. As with any product, use of Makrolon 2405, 2407, or 2458 resin in a given application must be tested (including but not limited to field testing) in advance by the user to determine suitability.

Medical Applications

Makrolon 2458 resin is used in a variety of medical devices.

Biocompatability: Certain color formulations of Makrolon 2458 polycarbonate resin (such as clear tint 550115) meet the requirements of the FDA-modified ISO 10993, Part 1 "Biological Evaluation of Medical Devices" tests with human tissue contact time of 30 days or less. Only products that meet these requirements may be considered candidates for applications requiring biocompatibility.

Regrind must not be used in medical applications requiring biocompatibility.

Manufacturer's Responsibility: It is the responsibility of the medical device, biological product or pharmaceutical manufacturer ("Manufacturer") to determine the suitability of all component parts and raw materials, including Makrolon 2458 resin, used in its final product in order to ensure safety and compliance with FDA requirements. This determination must include, as applicable, testing for suitability as an implant device and suitability as to contact with and/or storage of human tissue and liquids including, without limitation. medication, blood or other bodily fluids. Under no circumstances may Makrolon 2458 resin be used in any cosmetic, reconstructive or reproductive implant applications. Nor may Makrolon 2458 resin be used in any other bodily implant applications or any applications involving contact with or storage of human tissue, blood, or other bodily fluids for greater than 30 days, based on FDA-modified ISO 10993, Part 1 "Biological Evaluation of Medical Devices" tests.

The suitability of a Bayer product in a given end-use environment is dependent upon various conditions including, without limitation, chemical compatibility, temperature, part design, sterilization method, residual stresses, and external loads. It is the responsibility of the Manufacturer to evaluate its final product under actual end-use requirements and to adequately advise and warn purchasers and users thereof.

Single-use medical devices made from a Bayer product are not suitable for multiple uses. If the medical device is designed for multiple uses, it is the responsibility of the Manufacturer to determine the appropriate number of permissible uses by evaluating the device under actual sterilization and end-use conditions and to adequately advise and warn purchasers and users thereof.

Sterilization: Parts molded from Makrolon 2458 resin are sterilizable using radiation, ethylene oxide, or steam autoclaving. When sterilizing with steam, germicides and detergents must be rinsed thoroughly from polycarbonate parts prior to autoclaving. Failure to thoroughly remove germicides and detergents from the part prior to autoclaving may cause accelerated degradation of the polycarbonate.

Steam sterilization temperatures for parts made of Makrolon polycarbonate must not exceed 250° F (121°C) to avoid part deformation. Please note that permanent immersion of polycarbonate parts in water above 140°F (60°C) or in steam causes loss of material properties and must be avoided. Furthermore, condensed steam should not be allowed to accumulate, as this may cause damage to parts. Polycarbonate parts should also be protected from damage by substances such as alkaline corrosion inhibitors, which are frequently added to boiler feed water.

The sterilization method and the number of sterilization cycles a medical device made from Makrolon 2458 resin can withstand will vary depending upon type/grade of product, part design, processing parameters, sterilization temperature, and chemical environment. Therefore, the Manufacturer must evaluate each device to determine the sterilization method and the number of permissible sterilization cycles appropriate for actual end-use requirements and must adequately advise and warn purchasers and users thereof.

Drying

All polycarbonate resins are hygroscopic and must be thoroughly dried prior to processing. A desiccant dehumidifying hopper dryer is recommended. To achieve a moisture content of less than 0.02%, hopper inlet air temperature should be 250°F (121°C) and inlet air dew point should be -20°F (-29°C) or lower. The hopper capacity should be sufficient to provide a minimum residence time of 4 hours. Additional information on drying procedures is available in the Bayer brochure *General Drying Guide*.

Processing

Makrolon resins may be easily processed on commercially available molding equipment suitable for injection molding of polycarbonate. Barrel temperatures may be reduced by up to 45°F (25°C) below normal processing conditions for standard polycarbonate due to ease of cavity fill. Lower viscosity also means that lower primary and secondary injection pressures may be used and that molded-in stresses should be lower. A lower melt temperature permits the use of shorter hold and cure times. The shorter molding cycle is complemented by ease of part ejection at high par: temperatures.

Typical processing parameters are noted below. Actual processing conditions will depend on machine size, mold design, material residence time, shot size, etc.

Typical Injection Molding Conditions				
Middle Front Nozzle				
Injection Pressure Hold Pressure Back Pressure Screw Speed Injection Speed Cushion				

Additional information on processing may be obtained by consulting the Bayer publication *Makrolon Polycar-bonate*—A *Processing Guide for Injection Molding* and by contacting a Bayer Corporation technical service representative.

Regrind Information

Where end-use requirements permit, up to 20% Makrolon resin regrind may be used with virgin material, provided that the material is kept free of contamination and is properly dried (see section on Drying). Any regrind used must be generated from properly molded parts, sprues, and/or runners. All regrind used must be clean, uncontaminated, and thoroughly blended with virgin resin prior to drying and processing. Under no circumstances should degraded, discolored, or contaminated material be used for regrind. Materials of this type should be properly discarded.

Improperly mixed and/or dried regrind may diminish the desired properties of Makrolon resin. It is critical that you test finished parts produced with any amount of regrind to ensure that your end-use performance requirements are fully met. Regulatory or testing organizations (e.g., UL) may have specific requirements limiting the allowable amount of regrind. Because third party regrind generally does not have a traceable heat history or offer any assurance that proper temperatures, conditions, and/or materials were used in processing, extreme caution must be exercised in buying and using regrind from third parties.

The use of regrind material should be avoided entirely in those applications where resin properties equivalent to virgin material are required, including but not limited to color quality, impact strength, resin purity, and/or load-bearing performance.

Regulatory Compliance Information

Some of the end uses of the products described in this bulletin must comply with applicable regulations, such as FDA, NSF, USDA, and CPSC. If you have any questions on the regulatory status of these products, contact your Bayer Corporation representative or Bayer's Regulatory Affairs Manager in Pittsburgh, Pa.

General Characteristics of Polycarbonate

Hydrolytic Stability. Parts molded from polycarbonate absorb only 0.15 to 0.19% water at room temperature and 50% relative humidity. Dimensional stability and mechanical properties remain virtually unaffected. Even with immersion in water, dimensional changes measure only about 0.5%. Although frequent, intermittent contact with hot water does not harm polycarbonate, continuous exposure to humidity or water at high temperatures (>140°F/60°C) is not recommended due to hydrolytic degradation, which reduces impact strength and tensile properties.

Gas Permeability. Steam permeability, measured on 100-μm thick film, is 15 g/m²·24 h (0.97 g/100 in²·24 h). Significant permeability also exists for other gases, such as hydrogen, carbon dioxide, sulfur dioxide, helium, ethylene oxide, and oxygen.

Chemical Resistance. Polycarbonate is resistant to mineral acids (even in high concentrations), a large number of organic acids, many oxidizing and reducing agents, neutral and acidic saline solutions, some greases and oils, saturated aliphatic and cycloaliphatic hydrocarbons, and most alcohols. It is important to note that polycarbonate is degraded by alkaline solutions, ammonia gas and its solutions, and amines.

Polycarbonate dissolves in a number of organic solvents, such as halogenated hydrocarbons and some aromatic hydrocarbons. Other organic compounds cause polycarbonate to swell or stress-crack, e.g., acetone and methyl ethyl ketone. Since chemical resistance to various media is dependent on variables, such as concentration, time, temperature, part design, and residual stresses, the above information should serve only as a guideline. It is imperative that production parts be evaluated under actual application conditions prior to commercial use.

Health and Safety Information

Appropriate literature has been assembled which provides information concerning the health and safety precautions that must be observed when handling the Makrolon resins described in this bulletin. Before working with these products, you must read and become familiar with the available information on their hazards, proper use, and handling. This cannot be overemphasized. Information is available in several forms, e.g., material safety data sheets and product labels. Consult your Bayer Corporation representative or contact Bayer's Product Safety and Regulatory Affairs Department in Pittsburgh, Pa.

Typical Properties*	ASTM Test Method	Makrolon [®] 2405/2407 ^b /2458 Resins	
for Natural Resin	(Other)	J.S. Conventional	SINS SI Metric
General Specific Gravity Density Specific Volume Mold Shrinkage Water Absorption, Immersion at 73°F (23°C): 24 Hours Equilibrium Melt Flow Rate ^a at 300°C/1.2-kg Load	D 792 D 792 D 792 D 795 D 570	0.043 lo/in³ 23.1 in³/lb 0.005=0.007 in/in 0.1	20 1.20 g/cm ³ 0.83 cm ² /g 0.005–0.007 mm/mm 12% 80%
Optical Transmittance at 0.125-in (3.2-mm) Thickness Haze at 0.125-in (3.2-mm) Thickness Refractive Index	D 1003 D 1003 D 542	88% <0.8% 1.586	
Mechanical Tens:le Stress at Yield Tens:le Stress at Broak Tens le Elongation at Yield Tens le Elongation at Break Tens le Elongation at Break Tens le Modulus (1 mm/min) Flexural Stress at 5% Strain Flexural Modulus Compressive Stress at Yield Impact Strength, Notched Izod: 73°F (23°C) 0.125-in (3.2-mm) Thickness Tensile Impact Strength, "S" Specimen: 0.125-in (3.2-mm) Thickness Rockwell Hardness: M Scale R Scale	D 638 D 638 D 638 D 638 D 790 D 790 D 790 D 695 D 256	11 350,000 lb/in² 12,000 lb/in² 340,000 lb/in² 11,000 lb/in² 14 ft-lb/in 250 ft-lb/in²	65 MPa 60 MPa % 5% 2.4 GPa 83 MPa 2.4 GPa 76 MPa 750 J/m 525 kJ/m ²
Thermal Deflection Temperature, Unannealed: 0.250-in (6.4-mm) Thickness 264-psi (1.82-MPa) Load 56-psi (0.46-MPa) Load Coefficient of Linear Thermal Expansion Thermal Conductivity Specific Heat Relative Temperature Index: 0.059-in (1.5-mm) Thickness Electrical Mechanical with Impact Mechanical without Impact	D 648 D 696 C 177 D 2766 (UL746B)	115	126°C 134°C 6.0 E-05 mm/mm/°C 0.20 W/(m·K) 1,172 J/(kg·K)
Vicat Softening Temperature, 50N; 50K/h Flammability** Oxygen Index UL94 Flame Class: 0.75-mm (0.030-in) Thickness 1.5-mm (0.059-in) Thickness 2.7-mm (0.106-in) Thickness 3.0-mm (0.118-in) Thickness	D 1525 D 2863 (UL94)	125°C 291°F 144°C 28% V-2 Rating V-2 Rating HB Rating HB Rating	
Weatherability UV Light Exposure and Hot Water Immersion Tests Makrolon 2407 and 2458 resins	(UL746C)	f1 rating	
Electrical Volume Resistivity (Tinfoil Electrodes) Surface Resistivity Dielectric Strength (Short Time Under Oil at 1-mm [0.04-in] and 73°F [23°C]) Dielectric Constant (Tinfoil Electrodes): 60 Hz	D 257 D 257 D 149 D 150	1.0 E+16 ohm-cm 1.0 E+16 ohm 810 V/mil 32 kV/mm 3.0 2.9	
Dissipation Factor (Tinfoil Electrodes): 60 Hz 1 MHz Arc Resistance: Stainless Steel Electrodes Tungsten Electrodes	D 150 D 495	0.0008 0.01 11 s 120 s	

^{&#}x27; These items are provided as general information only. They are approximate values and are not part of the product specifications. Type and

quantity of pigments or additives used to obtain opaque colors and special effects can affect material properties.

** Flammability results are based on small-scale laboratory tests for purposes of relative correparison and are not intended to reflect the hazards presented by this or any other material under actual fire concitions.

** For information on using melt flow as a quality control procedure, see the Bayer publication Makrolon Polycarbonate --- A Processing Guide for Internation on using melt flow as a quality control procedure, see the Bayer publication Makrolon Polycarbonate --- A Processing Guide

for Injection Molding.

⁵ Makrolon 2407 resin is UV-Stabilized.

Note: The information contained in this bulletin is current as of November 2002. Please contact Bayer Corporation to determine whether this publication has been revised.

Bayer Corporation

Plastics Division • 100 Bayer Road • Pittsburgh, PA 15205-9741 • Phone: 1-412-777-2000 • www.BayerPlastics.com

The manner in which you use and the purpose to which you put and utilize our products, technical assistance and information (whether verbal, written or by way of production evaluations), including any suggested formulations and recommendations are beyond our control. Therefore, it is imperative that you test our products, technical assistance and information to determine to your own satisfaction whether they are suitable for your intended uses and applications. This application-specific analysis must at least include testing to determine suitability from a technical as well as health, safety, and environmental standpoint. Such testing has not necessarily been done by us. Unless we otherwise agree in writing, all products are sold strictly pursuant to the terms of our stindard conditions of sale. All information and technical assistance is given without warranty or guarantee and is subject to change without notice. It is expressly understood and agreed that you assume and hereby expressly release us from all liability, in tort, contract or otherwise, incurred in connection with the use of our products, technical assistance, and information. Any statement or recommendation not contained herein is unauthorized and shall not bind us. Nothing herein shall be construed as a recommendation to use any product in conflict with patents covering any material or its use. No license is implied or in fact granted under the claims of any patent.

Sales Offices ...

1732C Redhill Avenue, Suita 175 Tryine CA 92614-5660 • 1-949-533-2351 • Fax: 1-949-752-1306 1000 Route 9 North, Suite 103, Woodbridge, NJ 07095-1200 • 1-732-726-8988

One Westbrook Corporate Center, Suite 710, Westchester, % 60154 • 1-708-492-1600 • Fax: 1-705-492-1031 2401 Walton Boulevard, Auburn Hills, MI 48326-1957 • 1-248-475-7700 • Fax: 3-248-475-7701

128 11/02

Printed on recycled paper 🐔 🌢

