


Vandagraph

Replacement of the Analox O2 EII Oxygen sensor SA2 EII 9B Kit Using Vandagraph R-33DE



1. Refer to manufacturers instructions. The following notes are a guide
2. Loosen the 4 screws located on the front cover.
 - a. This may be Yellow or Green
 - b. Front cover has the sensor EII adapter
3. The gasket seal is designed to prevent water leaking into the O2 EII and may therefore be tight.
4. Loosen the seal by moving the lid from side to side, and then and carefully lift the cover.
5. Disconnect the connector from the back of the sensor R-33DE
 - a. Wires to the connector are very fine and easily broken
 - b. Check they are intact and not corroded before removing from sensor
 - c. Also check the cable for corrosion; normally the wire turns black
6. Unscrew the sensor from the front cover.
7. Remove the new sensor from its pack and check it for leaks
8. Check the sensor has a rubber O-ring fitted at the base of the thread on the front of the sensor
9. Screw the sensor into the front cover finger tight and connect the R-33DE to the EII connector
10. Make sure the metal prongs on the connector are facing the sensor and the key on the connector matches the key on the socket.
11. Push in gently but firmly.
12. Replace the cover carefully taking care that the sensor locates properly and that you do not trap any wires
13. Do not over tighten the screws.
14. Ensure the **EII** adapter is fitted
15. Leave exposed to dry outdoor air for at least two minutes NB (All galvanic sensors can take an hour to fully stabilize after they have first been exposed to air to achieve maximum accuracy)
16. Calibrate to 20.9%
17. Dispose of the old sensor according to local regulations for Lead and Potassium Hydroxide solution



Vandagraph Ltd. 15, Station Road, Crosshills, Keighley, West Yorkshire. BD20 7DT
+44 (0) 1535 634900 Fax: +44 (0) 1535 635582
www.vandagraph.co.uk email sales@vandagraph.co.uk