

COMPANY OPERATING PROCEDURES

0019938

PACE TECH


P993E8

VM3/COP/33.21

Date: 21-Dec-01

Revision date: 7-Apr-11

Issue: 3



Equipment required: Soldering iron (0060120), solder (0050012), Wire stripper (0060030), Flush Cutter (0060010), Snipe nose pliers (0060021), 'helping hand' (0060145), Heat gun (0060100).

Parts list: Kit and parts required. (Continued over page)

D-Type female 9-pin Side			Redel male 7-pin Side		
Qty	Description	Part No.	Qty	Description	Part No.
1	D-type extension cable (Female side)	00956E8	1	Redel male 7-pin kit	0030791
			(1)	Sleeve (blue)	Kit
			(1)	Collett	Kit
			(1)	Connector Pin	Kit
			(1)	Outer Sleeve	Kit
			(1)	Strain Relief (blue)	0030792
			1	Ø6 x 43mm Clear heat shrink	0032331 (roll)
			1	Ø6 x 10mm heat shrink	0032321 (roll)
			1	Ø1.6 x 17mm heat shrink	0032310 (roll)

COMPANY OPERATING PROCEDURES

0019938

PACE TECH

P993E8

VM3/COP/33.21

Date: 21-Dec-01

Revision date: 7-Apr-11

Issue: 3

ASSEMBLY OPERATIONS

1. Pre Heat soldering iron temperature to 240°C.
2. Collect all required parts and equipment listed above.

D-type female 9-pin side:




Fig 2.1. 00956E8 Extension Cable.

1. The 00956E8 cable is already assembled. The female side does not need to be modified, but the male side needs to be cut off ready for the Redel male 7-pin connector to be fitted.

Redel male 7 pin side:




Fig 2.2

1. Feed Ø6 x 43mm (clear) heat shrink, strain relief, sleeve, collett, Ø6 x 10mm (black) heat shrink over end of cable.
2. Strip 20mm off outer jacket of wire to reveal coloured wires, outer shield, and nylon/paper wire packing.
3. Cut all packing to the base.
4. Strip 20mm off inner jacket of wire- to reveal black and white wires and the inner shield.

COMPANY OPERATING PROCEDURES

0019938

PACE TECH

P993E8

VM3/COP/33.21

Date: 21-Dec-01


Revision date: 7-Apr-11

Issue: 3


5. Twist outer and inner shields together.
6. Trim (tidy) ends of all wires and shields to the same length.
7. Strip jacket of every wire 2mm to reveal copper core.
8. Apply small amount of solder to ends of each wire and shields.
9. Heat Ø1.6 x 17mm heat shrink over twisted shield pair to insulate.
10. Solder wires and paired shields to the rear of the connector pins as shown in fig 2.2.
11. Place Ø6 x 10mm heat shrink over base of coloured wires and outer jacket and heat to shrink firmly around.
12. Push collet up to the connector pin, and screw the sleeve into the outer sleeve.

TESTING

1. Attach P856 to the D type connector, the Redel connector to a test lead and the test box connector marked 'A'.
2. Attach Redel 7-pin side to a BCI finger probe.
3. Check display is showing correct characteristics as shown below. (At correct switch positions)



NB: Gap to be at bottom of display
Position 2. IR, LED.



Position 4. Detector

4. If the gap is at the top of the screen then the LED is wired incorrectly.
5. 'Play' with wire at connections to see if any change in the display (i.e. flickering etc).
6. If there is any movement of signal, the extension wire must be taken apart and all connections checked and re-soldered. Then tested again until results are satisfactory.
7. Check the cable is of correct quality standard. (See VM/COP/30.11 for details).
8. Connect P856 9-Pin side to a BCI 71000A2 portable monitor and attach probe on finger to check SpO₂ level. (Ideal reading 95-100.)

Labelling

1. Labels: to be attached facing upwards as looking at the top of the probe.
 - 1 x CE Label
 - 1 x serial no. Label

COMPANY OPERATING PROCEDURES

0019938

PACE TECH

P993E8


VM3/COP/33.21

Date: 21-Dec-01

Revision date: 7-Apr-11


Issue: 3

- 1x Orange 'Do Not Throw Away' Label (correct one of two is dependant of country unit is being sold to).




Quality Assurance (QA)

1. Attach P546E8 9-Pin side to a Redel to D type adapter and the test box connector marked 'A'.
2. Attach Redel 7-pin side to a BCI finger probe.
3. Check display is showing correct characteristics as shown below. (At correct switch positions)



NB: Gap to be at bottom of display
Position 2. IR, LED.



Position 4. Detector

4. If the gap is at the top of the screen then the LED is wired incorrectly.
5. 'Play' with wire at connections to see if any change in the display (i.e. flickering etc).
6. If there is any movement of signal, the extension wire must be taken apart and all connections checked and re-soldered. Then tested again until results are satisfactory.
7. Check the cable is of correct quality standard. (See VM/COP/30.11 for details).
8. Connect P546E8 9-Pin side to a BCI 71000A2 portable monitor and attach probe on finger to check SpO₂ level. (Ideal reading 95-100.)
9. Fill and sign attached paperwork.

Packaging

1. Visually check all labels are attached properly

COMPANY OPERATING PROCEDURES

0019938

PACE TECH

P993E8

VM3/COP/33.21

Date: 21-Dec-01

Revision date: 7-Apr-11

Issue: 3

2. Using a twist tie (bunny clip) wrap the cable and place in a small blue Viamed plastic box, ensuring the cable is inserted in a neat and tidy presentable manor.
3. Place a serial number sticker (supplied with the batch) on the front face of the box.
4. Place a packed and tested sticker (also containing initials of the individual who is packing) on the right hand side top left corner of the box. Do not close box.

Final QA

1. Final inspection. Visually ensure cable sit neatly within the box and is in a presentable state.
2. Boxes are ready to stock in stores.